



# Vogl Painting Instructions

The Association of Wall & Ceiling Industries (AWCI) and the Australian Paint Manufacturer's Federation (APMF) have established recommendations for the finishing of plasterboard which includes our VoglFuge Ceiling panels.

## **AS/ANZS 2311:2017**

As defined in Australian Standard AS/ANZS 2311:2017- Guide to the Painting of Buildings is to deliver the appearance of a uniform surface texture and colour.

## **Three coat system:**

A per AS/ANZS 2311:2017 painting of plasterboard must comprise a 3-coat system with a short nap roller. Failure to do so may result in joints being visible and warranty voided.

- Sealer Undercoat x 1
- Top Coat X 2

## **Decor Systems Recommendation:**

- Use light coloured paint only
- Don't use gloss paint
- Use a suitable sealer undercoat
- Use good quality paint
- Allow sufficient drying time between coats
- Do not use a spray gun to paint plasterboard
- Apply paint with a short nap paint roller only

## **Warranty:**

Plasterboard and paint systems must be installed and applied strictly in accordance with the manufacturer's specifications and those of the applicable Australian Standards for the performance and integrity including the jointing and paint systems for VoglFuge to be warranted.



[www.decorsystems.com.au](http://www.decorsystems.com.au)



LET'S MAKE  
**WOW!**

P: 1800 835 035

E: [letstalk@decorsystems.com.au](mailto:letstalk@decorsystems.com.au)

Sydney | Perth | Melbourne | Brisbane | Christchurch